

Additional handle information

There are two types of handle available for single opening doors; the most common used is the Lever/Lever Style (both handles are the same in and out).



To lock from outside or inside - lift the handle upwards to its maximum position, insert the key and turn clockwise. Reverse the operation to unlock depressing the handle downwards.

If a Thumb Turn cylinder has been specified internally, the procedure is the same when standing outside the door, but when inside instead of inserting a key simply turn the wheel clockwise, to unlock turn the wheel anti-clockwise then depress the handle.

The other type of handle is Lever/ Pad or Split / Lever Lever, this works similar to a traditional door lock. When the door is closed it can only be opened from the outside with a key which releases the latch.

This means the door can be pulled closed



whilst providing easy exit for day to day use. The underlying factor is the door DOES NOT benefit from the high security lock nor weathering performance as the main gearing has not been engaged.

This can only be operated as described above (use the Pad the same way as the Lever Handle).

To unlock the Pad or Split Lever handle externally insert the key & turn anti clockwise push down the handle which will release the high security locking system but NOT the latch.

Turn the key once more anti clockwise to retract the latch whilst holding down the handle.

The door will now open.

The internal operation of locking and unlocking with a key or thumb turn cylinder remains the same as above.

To ensure Weather tightness and ensuring the door functions properly as per the manufacturers Warranty the Locking gearing must be engaged every time the door is used / closed. Failure to do so may compromise the conditions of the warranty.